

# Agricultural Valve

are available in various types and suitable for closing or reduce level of water flow. Suitable for farmers who want to open the water as a zone. Also, control the flow rate of each valves to suit for the farmers to cultivate.




# Agri Valve


This valve is for adjustable the pressure of water in the systems. It is not recommended as a shut off of water.

- 3 O'Ring in Agri Valve
- 1 O'Ring in Agri Valve Tantawan
- 3 O'Ring in Agri Valve Big Body Valve


## Agri Valve - PE Pipe

	Code Number	Size (mm)	Pack Size (bag)
	380-16-20	16x20	100
	380-20	20x20	100
	380-25	25x25	100

## Agri Valve - PE Pipe - Male Thread


	Code Number	Size (mm x inch)	Pack Size (bag)
	383	16x1/2"	100
	383-20	20x1/2"	100
	386	25x1/2"	100

## Agri Valve - PE Pipe Rubber Gasket Connector


	Code Number	Size (mm)	Pack Size (bag)
	384-16-20	16x20	100
	384-20	20x20	100
	384-25	25x25	100

378-16  
378-20  
378-25


## Agri Valve - PVC Pipe

	Code Number	Size (inch)	Pack Size (bag)
	388-1	1/2"	100
	388-2	3/4"x1/2"	100
	388-3	3/4"	100


## Agri Valve - PVC - PE Pipes

	Code Number	Size (inch x mm)	Pack Size (bag)
	382-1	1/2"x16	100
	382-2	1/2"x20	100
	382-3	1/2"x25	100
	382-4	3/4"x16	100
	382-5	3/4"x20	100
	382-6	3/4"x25	100

## Agri Valve - PVC - PE Fittings

	Code Number	Size (inch x mm)	Pack Size (bag)
	387-1	1/2"x16	100
	387-2	1/2"x20	100
	387-3	1/2"x25	100
	387-4	3/4"x16	100
	387-5	3/4"x20	100
	387-6	3/4"x25	100

## Agri Valve - PVC Pipe Male Thread

	Code Number	Size (inch)	Pack Size (bag)
	381	1/2"x1/2"	100
	385	3/4"x1/2"	100

# Agri Valve Tantawan

## Agri Valve Tantawan - PE Pipe



Code Number	Size (mm)	Pack Size (bag)
389-30R	16	100
389-31R	20	100
389-32R	25	100

## Agri Valve Tantawan - PVC Pipe



Code Number	Size (inch)	Pack Size (bag)
389-20R	1/2"	100
389-21R	3/4"x1/2"	100
389-22R	3/4"	100

## Agri Valve Tantawan - PVC - PE Fittings



Code Number	Size (inch x mm)	Pack Size (bag)
389-60R	1/2"x16	100
389-61R	1/2"x20	100
389-62R	1/2"x25	100
389-63R	3/4"x16	100
389-64R	3/4"x20	100
389-65R	3/4"x25	100

## Agri Valve Tantawan - PVC Pipe - Male Thread



Code Number	Size (inch)	Pack Size (bag)
389-10R	1/2"x1/2"	100
389-11R	3/4"x1/2"	100
389-12R	3/4"x3/4"	100



## TIPS

All Agricultural Valves are only used for reducing the pressure of water in the system. They cannot turn off 100% of water. Ball Valve is recommended for closed water tightly.



## Agri Valve Big Body - PE Pipe



Code Number	Size (mm)	Pack Size (bag)
388-90	16	100
388-91	20	100
388-92	25	100

## Agri Valve Big Body - PVC Pipe



Code Number	Size (inch)	Pack Size (bag)
388-10	1/2"	100
388-12	3/4"	100
388-13	1"	100

## Agri Valve Big Body - PVC - PE Pipes



Code Number	Size (inch x mm)	Pack Size (bag)
388-30	1/2"x16	100
388-31	1/2"x20	100
388-32	1/2"x25	100
388-33	3/4"x16	100
388-34	3/4"x20	100
388-35	3/4"x25	100
388-36	1"x32	100

## Agri Valve Big Body - PVC - PE Fittings



Code Number	Size (inch x mm)	Pack Size (bag)
388-40	1/2"x16	100
388-41	1/2"x20	100
388-42	1/2"x25	100
388-43	3/4"x16	100
388-44	3/4"x20	100
388-45	3/4"x25	100
388-46	1"x32	100

## Agri Valve Big Body - PVC Pipe - Male Thread



Code Number	Size (inch)	Pack Size (bag)
388-20	1/2"x1/2"	100
388-22	3/4"x3/4"	100

## Agri Valve Big Body - PE Pipe - Male Thread



Code Number	Size (inch x mm)	Pack Size (bag)
388-50	1/2"x16	100
388-51	1/2"x20	100
388-52	1/2"x25	100
388-53	3/4"x16	100
388-54	3/4"x20	100
388-55	3/4"x25	100
388-56	1"x32	100